

Sensilia is a digital companion designed for a social use. It encourages sharing with family members and the nursing staff and enhances well-being.

The device is made for elderly users who don't master personal computers and whose social network is weakening due to the estrangement and geographical distancing from relatives. It is mostly appreciated in collective dwellings such as retirement homes, nursing homes, senior citizens gatherings...

Its entirely tactile interface is designed for novice users, its logging in process simplified by the use of RFID cards both make Sensilia a service that is simple of use, intuitive and user-friendly.

Anyone can learn to master it in a few minutes with no help.

design by



transversal design
3, rue platon
87100 LIMOGES



**User
guide**

Sensilia is a Trade mark of AM Paris - RCS 491 508 461 Paris

The richness of a simple, intuitive
and tactile digital environment
to keep in touch

Sensilia
16, boulevard Saint-Germain
75005 PARIS

contact@sensilia.com

www.sensilia.com

sensilia

You have a parent or a friend who resides in a foster home equipped with Sensilia.

Sensilia is an array of digital services that help maintain social connections with your relatives despite distance.

This guide introduces you to these services. It displays the principal functions of your personal Sensilia area on the Internet. A place you can access from any computer connected to the Internet.

Your fostering a sharing relationship with your parent or friend will help them on a daily basis to experience this new step of their life more pleasantly. A picture taken during a family reunion and shared with them, a few words sent from time to time, an anecdote told through the service are all clusters of presence that will warm their heart.

The whole Sensilia team hopes these services will contribute to the well-being of your relatives.

If you want to share any feedback or suggestion with us, please use your reserved email address : relatives@sensilia.com

We thank you in advance.

The use of your account is completely free of charge and without limitations.

my login

My password

www.myaccount.sensilia.com

Create your account

Go to www.myaccount.sensilia.com, choose "Sign up". Fill in all the categories, choose your password and submit the form. It is mandatory to complete your profile with a picture because this will allow your contacts to identify you and your messages more easily.

Add a contact

In the "My account" menu, choose "My network", then click on "Add a contact".

In order to add a contact you need to know precisely their first and last name and town of residence.

You must then enter a nickname for your contact.

Once your request has been sent, it is moved to the "Pending Requests" folder and your correspondent is warned of your demand. Once he accept it, you will be part of his network and will be able to start communicating with him.

It is not possible to communicate with a user until he has accepted you as a part of his network.

Receive an add request

A user can ask you to join his network. If you don't have a Sensilia account yet, you will receive an email with his request.

If you do possess a Sensilia account, his request will show up in the "Pending Requests" folder where you will have to validate it.

Find the complete user guide on www.sensilia.com by clicking on "Download documentation" on the lower part of your screen,

Sending a message

Choose "Send a message" in the "Messages" menu. Type your message then click on "Send". Your message will appear on your contact's Sensilia. Once you've clicked on "Send", your message is archived in the "My Sent Messages" folder. If you click on "Cancel" your message is deleted and not sent.

Receiving your messages

You can read your new messages by clicking on "My New Messages"

The name of the sender, the sending date and the first words of every received message will show on your screen. By clicking on the name of the sender, the message will appear in its entirety. To answer to a message click on "Answer".

Sending a picture

Choose "Send a Picture" in the "Pictures" menu.

Click on the "Choose a file" button. Your computer's file browser will appear. Browse through your files in order to choose the picture you want to send. Click on "Send". Your picture is then sent to your contact and will appear on her Sensilia.

If you click on "Cancel", your picture isn't sent.

You can only send pictures that have jpeg, gif and png extensions and weighs less than 1 Mo.

Sending a reminder

Choose "Send a Reminder" in the "Reminder" menu. Choose the date at which you want the reminder to show up on your contact's Sensilia. Type your reminder's text and choose its color. Click on "Send". The reminder appears on your contact's Sensilia at the date you chose.

If you click on "Cancel", your reminder is deleted and not sent.